Operating Instructions

FILE-TYPE COMPACT DISC PLAYER

PD-F905

CDFILE 101-DISC

COMPACT disc DIGITAL AUDIO



The illustration shows U.S. model.

POWER ON DEMO display

POWER ON DEMO display mode allows you to see variations of the display. To enter the POWER ON DEMO display mode, press POWER and then ⏮ ◀◀ within 1 second after turning on the power.

To cancel the POWER ON DEMO display mode, press any button.

Thank you for buying this Pioneer product.
Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.
In some countries or regions, the shape of the power plug and power outlet may sometimes differ from that shown in the explanatory drawings. However, the method of connecting and operating the unit is the same.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

IMPORTANT NOTICE

The serial number for this equipment is located on the rear panel. Please write this serial number on your enclosed warranty card and keep it in a secure area. This is for your security.

THE POWER SWITCH IS SECONDARY CONNECTED AND THEREFORE DOES NOT SEPARATE THE UNIT FROM MAINS POWER IN THE STANDBY POSITION.

[For European and U.K. Models]
This product complies with the Low Voltage Directive (73/23/EEC), EMC Directives (89/336/EEC, 92/31/EEC) and CE Marking Directive (93/68/EEC).

CAUTION [For U.S. Model]
This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances such as radios and televisions, use shielded cables and connectors for connections.

CONTENTS

BEFORE YOU USE THE PLAYER 4
CAUTIONS REGARDING HANDLING 5
CONNECTIONS 6
NAMES OF PARTS 7
HOW TO LOAD THE DISCS 9

BASIC OPERATIONS
- To listen in order from the first track 10
- To select the disc and track 10
- To select a play mode 10
- Playing a disc in the Single Loader slot 11
- The hood can be opened or closed during playback 11

VARIOUS OPERATIONS
- To program and play only the discs you want to hear 12
- To start playback from a specific disc 13
- To play a track you want to hear 13
- To repeat playback 13
- To playback tracks/discs at random 14
- To program tracks/discs in a desired order 15
- To store your favorite tracks 16
- To find out which discs you've listened to recently 16
- To scan quickly through tracks on a disc 17
- ADLC (Automatic Digital Level Controller) 18
- To use the TIME button 18

TROUBLESHOOTING 19
SPECIFICATIONS 20

This player is for consumer use. If the player is used in a business (for example, used for a long period at a restaurant), the player will not be covered under warranty.

PIONEER
The Art of Entertainment

IMPORTANT

The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

SAFETY INSTRUCTIONS

READ INSTRUCTIONS – All the safety and operating instructions should be read before the appliance is operated.

RETAIN INSTRUCTIONS – The safety and operating instructions should be retained for future reference.

HEED WARNING – All warnings on the appliance and in the operating instructions should be adhered to.

FOLLOW INSTRUCTIONS – All operating and use instructions should be followed.

WATER AND MOISTURE – The appliance should not be used near water – for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.

LOCATION – The appliance should be installed in a stable location.

WALL OR CEILING MOUNTING – The appliance should not be mounted to a wall or ceiling.

VENTILATION – The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

HEAT – The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.

POWER SOURCES – The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

POWER-CORD PROTECTION – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

POLARIZATION – If your purchased product is provided with a polarized power plug, please read the following instructions. This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

CLEANING – The appliance should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzine, insecticides or other volatile liquids since they may corrode the cabinet.

POWER LINES – An outdoor antenna should be located away from power lines.

NONUSE PERIODS – The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

OBJECT AND LIQUID ENTRY – Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

DAMAGE REQUIRING SERVICE – The appliance should be serviced by a Pioneer authorized service center or qualified service personnel when:

- The power-supply cord or the plug has been damaged.
- Objects have fallen, or liquid has been spilled into the appliance.
- The appliance has been exposed to rain.
- The appliance does not appear to operate normally or exhibits a marked change in performance.
- The appliance has been dropped or the enclosure damaged.

SERVICING – The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

OUTDOOR ANTENNA GROUNDING – If an outside antenna is connected to the antenna terminal, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.
In the U.S.A. section 810 of the National Electrical Code, ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Fig. A.

CART – An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

NEC – NATIONAL ELECTRICAL CODE


ANTENNA LEAD-IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810 – 20)
ELECTRIC SERVICE EQUIPMENT
GROUNDING CONDUCTORS (NEC SECTION 810 – 21)
GROUND CLAMPS
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250, PART H)

FIG. A

[FOR EUROPEAN AND U.K. MODELS]

CAUTION

This product contains a laser diode of higher class than 1. To ensure continued safety, do not remove any covers or attempt to gain access to the inside of the product.
Refer all servicing to qualified personnel.

The following caution label appears on your player.

Location: rear of the player

CLASS 1
LASER PRODUCT
VRW-328

IMPORTANT

FOR USE IN THE UNITED KINGDOM

The wires in this mains lead are coloured in accordance with the following code :

Blue: Neutral
Brown: Live

If the plug provided is unsuitable for your socket outlets, the plug must be cut off and a suitable plug fitted.

The cut-off plug should be disposed of and must not be inserted into any 13 amp socket as this can result in electric shock. The plug or adaptor or the distribution panel should be provided with a 5 amp fuse. As the colours of the wires in the mains lead of this appliance may not correspond with coloured markings identifying the terminals in your plug, proceed as follows:
The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Do not connect either wire to the earth terminal of a three-pin plug.

NOTE
After replacing or changing a fuse, the fuse cover in the plug must be replaced with a fuse cover which corresponds to the colour of the insert in the base of the plug or the word that is embossed on the base of the plug, and the appliance must not be used without a fuse cover. If lost, replacement fuse covers can be obtained from your dealer.
Only 5 A fuses approved by B.S.I. or A.S.T.A. to B.S 1362 should be used.

[FOR U.S. MODEL]
CAUTION

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- The use of optical instruments with this product will increase eye hazard.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Information to User
Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

[For Canadian model]
CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.
[Pour le modèle Canadien]
ATTENTION: POUR PREVENIR LES CHOCS ELECTRIQUES NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

[For Canadian model]
This Class B digital apparatus meets all requirements of the Canadian Interference–Causing Equipment Regulations.

[Pour le modèle Canadien]
Cet appareil numérique de la Classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

POWER-CORD CAUTION

Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or an electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or pinch the cord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause a fire or give you an electrical shock. Check the power cord once in a while. When you find it damaged, ask your nearest PIONEER authorized service center or your dealer for a replacement.

BEFORE YOU USE THE PLAYER

HERE'S WHAT YOU CAN DO!

❑ Up to 100 CDs can be registered by classifying them into 3 categories (CUSTOM). [10 page]

For example, if you register you own discs in CUSTOM I, your mother's discs in CUSTOM II and your father's discs in CUSTOM III or if you select three kinds of music genres or artists and register them in the three CUSTOM banks, you can play all of the discs classified under one of the three CUSTOM banks. Addition of discs to already-registered discs is also possible. Each of the three CUSTOM banks can register up to 100 discs.

❑ Single Loader slot is provided. [11 page]

If you have a disc borrowed from a friend, you can play only that disc by loading it in this special slot (Disc No. 0), without replacing discs stored in the rack.

❑ ADLC (Automatic Digital Level Control) reduces the problem of the volume difference between discs by averaging it. [18 page]

The 100 discs are not recorded in the same way. For example, when there is a difference in volume between rock and classic music discs, it would usually be necessary to adjust the amplifier volume every time the disc is changed. But the ADLC function eliminates the need of this volume adjustment operation.

❑ Immediately access and play your favorite tracks from among the 100 discs loaded in the player. [16 page]

The Best Selection Memory function lets you store and play favorite tracks with the touch of a single button (up to 20 tracks).

❑ Easy access to the disc(s) you've listened to recently. [16 page]

The Previous Disc Scan function recalls the last disc you played and then moves one by one through the previously played discs (auto-memory of last 20 discs played).

CONFIRM SUPPLIED ACCESSORIES

Remote control unit x 1



Output cable x 1



Size AA/R6P dry cell batteries x 2



Control cable x 1 (Except for European and U.K. models)



CD liner notes file x 1



Index label sheet x 1

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

- Please use the index label sheet with the CD liner notes file.

PUT BATTERIES INTO THE REMOTE CONTROL UNIT



Open the lid of the battery compartment on the rear of the remote control unit, and insert the batteries, taking care to align the ⊕ and ⊖ polarities correctly.

Notes!!:

- *In order to prevent battery leakage, remove the batteries when not using the remote control unit for an extended period (one month or more). If leakage occurs, carefully wipe away any battery fluid inside the compartment, and replace the batteries with new ones.*
- *Do not allow books or other objects to rest on top of the remote control unit, since the buttons may be depressed, causing faster exhaustion of the batteries.*

Incorrect use of batteries may cause leakage or rupture.
Always be sure to follow these guidelines:

A. Always insert batteries into the battery compartment correctly matching the positive ⊕ and negative ⊖ polarities, as shown by the display inside the compartment.
B. Never mix new and used batteries.
C. Batteries of the same size may have different voltages, depending on brand. Do not mix different brands of batteries.

CAUTIONS REGARDING HANDLING

Location

Install the player in a well-ventilated location where it will not be exposed to high temperatures or humidity.
Do not install the player in a location which is exposed to direct rays of the sun, or near stoves or radiators. Excessive heat can adversely affect the cabinet and internal components. Installation of the player in a damp or dusty environment may also result in a malfunction or an accident. (Avoid installation near cookers etc., where the player may be exposed to oily smoke, steam or heat.)
Do not install the player on a tottered stand nor in an unstable or inclined place.

Precautions regarding installation

- Placing and using the compact disc player for long periods on heat-generating sources such as amplifiers will affect performance. Avoid placing the player on heat-generating sources.
- Install this compact disc player as far as possible from tuners and TV sets. A compact disc player installed in close proximity to such equipment may cause noise or degradation of the picture.
- Such noise may be particularly noticeable when an indoor antenna is used. In such cases, make use of an outdoor antenna, or turn off power to the compact disc player.
- **Please place this unit on a level surface.**

Cleaning the player

To clean the PLAYER, wipe with a soft, dry cloth. For stubborn dirt, wet a soft cloth with a mild detergent solution made by diluting one part detergent to 5 or 6 parts water, wring well, then wipe off the dirt. Also use a dry cloth to wipe the surface dry. Do not use volatile liquids such as benzene and thinner which are harmful to the unit.

Storing discs

- Discs are made of the same kinds of plastic used for conventional analog audio records. Be careful not to allow discs to warp; always store discs in their cases vertically, avoiding locations with high heat or humidity, or extremely low temperatures. Avoid leaving discs in cars, since the seat of a car in direct sunlight can become unbelievably hot.
- Always read and abide by the precautionary notes listed on disc labels.



CD lens cleaner

The player's pickup lens should not become dirty in normal use, but if for some reason it should malfunction due to soiling, consult your nearest PIONEER authorized service center. Lens cleaners for CD players are commercially available, but special care should be exercised in their use since some may cause damage to the lens.

Condensation

When this unit is brought into a warm room from previously cold surroundings or when the room temperature rises sharply, condensation may form inside, and the unit may not be able to attain its full performance. If this occurs, allow the unit to stand for about an hour or raise the room temperature gradually.

Cleaning and handling compact discs

- The presence of fingerprints or smudges on the surface of the disc will not directly affect the recorded signals, but depending on the degree of contamination, the brightness of the light reflected from the signal surfaces may be reduced, causing degradation of sound quality. Always keep your discs clean by wiping them gently with a soft cloth from the inner edge toward the outer periphery.



- If a disc becomes very dirty, dip a soft cloth in water, and after wringing it out well, wipe the dirt away gently, and then remove any water drops with another soft, dry cloth.
- Do not use record cleaning sprays or anti-static agents on discs. Also, never clean discs with benzene, thinner, or other volatile solvents, since damage to the disc surface may result.

- With this player, use discs which display the mark shown below. (Optical audio digital discs.)
- When holding discs, do not touch their signal surfaces. Hold by the edges, or by one edge and the center hole.
- Do not affix gummed labels or tape to the label surfaces. Also, do not scratch or damage the label.
- Discs rotate at high speed inside the player. Do not use damaged (cracked or warped) discs.



Re-transporting

When re-transporting this unit in the future, remove all discs from the rack. Turn off the POWER STANDBY/ON switch, wait for "OFF" to go out from the display, and unplug the power cord.

CONNECTIONS

Before making or changing the connections, switch off the power switch and disconnect the power cord from the AC outlet.



Ⓐ Making connections

1 Connect the **OUTPUT** jacks of this unit to the input jacks (CD or AUX) of the amplifier. Make sure that the white plugs are connected to the left (L) jacks and the red plugs to the right (R) jacks.

- Be sure not to connect this unit to the amplifier's **PHONO** jacks, as sound will be distorted and normal playback will not be possible.

2 Connect the power cord to a household AC wall outlet.

- Make sure plugs are inserted fully into the wall outlet.

Note!!:

Do not connect the power cord to an AC outlet on your amplifier. If you connect the power cord to a "SWITCHED" AC outlet on an amplifier, you will not be able to use this unit's memory function.

Ⓑ Connecting the OPTICAL FIBER CABLE

This unit can be connected to an amplifier equipped with an optical digital jack.

1. Remove the protective dust cap from this unit's **DIGITAL OUT OPTICAL** jack.
2. Use an optical fiber cable to connect the **DIGITAL OUT OPTICAL** jack of this unit to the optical input jack of the amplifier.

- Align the plug of the optical fiber cable with the optical digital jack and fully insert the plug to make a secure connection.

Use a separately sold optical fiber cable for the optical digital jack connections.

Precautions concerning use of optical fiber cables

- Fully insert the optical fiber cable plugs all the way into the jacks.
- Be careful not to fold or crimp the cable. When coiling an optical fiber cable for storage, make sure the diameter of the coil is 15 cm (6 in.) or larger.
- Use an optical fiber cable with a length of 3 m (10 ft.) or less.
- Protect the optical fiber cable plugs from scratches and dust.
- When the unit is not connected using an optical fiber cable, be sure to keep the protective dust cap plugged into the optical digital output jack at all times.

Ⓒ System remote control with a Pioneer stereo amplifier that has the SR mark (except for European and U.K. models)

When a Pioneer stereo amplifier bearing the SR mark is used, connect the **CONTROL IN** jack on the rear panel of the CD player to the **CONTROL OUT** jack of the amplifier. This will enable the CD player to be controlled using the remote control unit supplied with the stereo amplifier. If you do not plan to use this feature, it is not necessary to connect the **CONTROL IN/OUT** jacks.

- The remote control unit supplied with the amplifier can be used to control Play, Stop, Pause, Track/Disc Search and Disc Change operations.
- For instructions regarding connections and operation, refer to the operating instructions provided with your stereo amplifier.

Notes!!:

- *When a control cable is connected to the player's **CONTROL IN** jack, direct control of the player with the remote control unit is not possible. Operate the player with the remote control unit by aiming it at the amplifier.*
- *Be sure to connect both of the control cable's plugs securely to the **CONTROL IN** and **CONTROL OUT** jacks. Do not connect only one end of the cable.*
- *Be sure to turn off the power of the amplifier before connecting the power cord and output cable.*
- *The CONTROL IN jack on the European model is for connecting the PD-AP1 controller.*

Ⓓ CD-Deck synchro function

If you have a Pioneer cassette deck provided with the CD-Deck synchro function, connect the **CD-DECK SYNCHRO** jacks of the CD player and cassette deck. With this function, synchro recording can be carried out between the player and deck.

- For details on connections and operation, refer to the operating instructions supplied with the cassette deck.
- The CD-DECK SYNCHRO cable is not supplied with the CD player.
- When CD-Deck synchro recording is carried out on several discs, use the program playback function. (Refer to page 14 for details of program playback.)

Note!!:

In order to enable the CD-DECK SYNCHRO recording function, the Output cable must be connected to the stereo amplifier.

Ⓔ I/O INTERFACE (except for U.K. model)

Terminal for connecting the controller (optional). The PD-AP1 is capable of simultaneous control of up to 3 units of this model.
When using the optional controller, use the I/O interface with the CONTROL IN jack.

(Refer to 18 page)

NAMES OF PARTS

FRONT PANEL

●The numbers in parenthesis ( ) are reference pages.



Note!!:
* mark is except for U.S. model

BEFORE OPERATING

DISPLAY



REMOTE CONTROL UNIT

●The numbers in parenthesis ( ) are reference pages.



REMOTE CONTROL OPERATIONS



When operating the remote control unit, point the unit's infrared signal transmitter at the remote control receiver (Remote Sensor) on the front panel of the player. The remote control unit can be used within a range of about 7 meters (23 feet) from the remote sensor, and within angles of up to about 30 degrees.

Note!!:
If the remote control sensor window is in a position where it receives strong light such as sunlight or fluorescent light, control may not be possible.

HOW TO LOAD THE DISCS (Be sure to read this before operation)

Loading discs into the rack

- You can load up to **100 discs** in the rack.
  The numbers marked on the rack are used as the disc numbers. These are marked in the clockwise order from **1** to **100**.
- **The following procedure describes how to load discs from disc No. 1.**

1 POWER STANDBY/ON

Press POWER switch.

- Ensure that the disc No. shown on the display is "1".
- If the displayed disc No. is not "1", press **DISC(–/+)** to display "1".

2 UNLOAD



Press UNLOAD.



The hood will open.

When **UNLOAD** is pressed, the hood opens to the disc corresponding to the disc No. displayed on the front of the unit. Therefore, if you want to load discs from No. 50, use **DISC (+/–)** on the unit to display "50", or enter "50" using the remote control unit, before pressing **UNLOAD**.

3



Load the disc into the rack with the label side (printed surface) facing to the left.

Side to be played faces right (label side faces left)

4 DISC



Press DISC(+) to rotate the rack.

- The rack rotates in the direction of 1,2,3.... Pressing **DISC(–)** rotates the rack in the opposite direction.

5 **Load other discs into the rack by repeating steps 3 and 4 for each of them.**

6

Press OPEN/CLOSE.

- The hood will close.

Tip:
Difference between **OPEN/CLOSE** and **UNLOAD**
OPEN/CLOSE: The hood is simply opened or closed.
UNLOAD: The slot corresponding to the disc No. being displayed rotates to the center position then the hood is opened.

Notes!!:

- ***Do not attempt to open the hood with your hand.***
- *Be careful not to pinch your fingers when opening and closing the hood.*

- If a disc is inserted with its label side facing to the right, it cannot be played back. Be sure to load all discs with their label sides facing to the left.

⚠ WARNING:
Do not put your hand or any other object inside the rack, otherwise injury or part damage may result.



- **Do not put anything other than CDs inside the rack.**
- **Do not use adapters for 8-cm (3-in.) CDs.**
- Load only one disc into each disc slot.
- Inserting an 8-cm (3-in.) CDs in between two 12-cm (5-in.) CDs, will make it difficult to remove the 8-cm (3-in.) CD.
  We recommend inserting 12-cm (5-in.) CDs starting from Disc No. 1 (i.e., 1, 2, 3...) and 8-cm (3-in.) CDs starting from Disc No. 100 (i.e., 100, 99, 98...).
- The unit will not operate if the hood is opened during playback. Be sure to close the hood before attempting any operations.

- To load or remove a disc in or from the slot which is seen through the hood, press **OPEN/CLOSE**. The hood is opened, **"HOLD"** is displayed and the disc can be loaded in or ejected from the slot seen through the hood. Even while **"HOLD"** is being displayed, the rack can be rotated by pressing **DISC (-/+)**.
- Be sure to remove all discs from the rack, set the **POWER** switch to off (Standby), and unplug the power cord before moving the unit.

To remove the discs...

1. **Press UNLOAD.**
2. **Select the disc No. to be removed by pressing DISC(-/+).**
   - The rack rotates until the selected disc comes in the front of the unit.
3. **Remove from the rack.**
4. **Press OPEN/CLOSE.**
   - The hood will close.

BEFORE OPERATING

BASIC OPERATIONS

- You can also use the remote control.



To listen in order from the first track

1 POWER STANDBY/ON

Press POWER.



To turn the power off...
Press **POWER** again.
STANDBY indicator lights (except for U.S. model).

2 **Load discs into the rack.**



Press OPEN/CLOSE.

Side to be played faces right (label side faces left)

Note!!

- *Inserting more than one disc into the slot will damage the discs and cause the unit to malfunction.*

3 **Press ▶/II.**

The tracks are played in order starting from the first track on the disc with the lowest disc No.

- If you choose a play mode beforehand, the tracks/discs are played back according to the respective play mode.

To stop play

Press ■.

To pause play

Press ▶/II.
To start playback again, press ▶/II.

To skip to another track

Tap ⏮◀◀◀◀/▶▶▶▶⏭ (or ⏮◀◀/▶▶⏭ on the remote control unit).

To fast forward/reverse.



Hold-down ⏮◀◀◀◀/▶▶▶▶⏭ (main unit only).

To select the disc and track



Use the digit buttons to select the disc, then press DISC SET.



Use the digit buttons to select the track, and press TRACK SET.

To select a play mode

Press MODE during play or stop mode.
Press a few times to choose the mode you desire.
Playback occurs according to the chosen mode.

ALL: All discs are played back.
SINGLE: One disc is played back.
CUSTOM (I,II,III): Only discs stored in the CUSTOM file are played back (see page 12 to create a custom file).

In stop mode: ALL → SINGLE → CUSTOM(III → II → I) → ALL

During playback: ALL → SINGLE → ALL

- When you select SINGLE during playback, only the current disc will be played.
- If you press **MODE** during program mode, the program contents will be erased.

Notes!!

- *When you turn the power ON, playback starts according to the last selected play mode.*
- *If you did not select a play mode, playback starts in ALL.*
- *SINGLE is selected automatically when playing the disc loaded in the Single Loader slot.*

<Last disc memory>
When you press ■ or turn the power OFF, the unit memorizes the disc that was being played. The next time you press ▶/II, playback will start from that same disc.



Playing a disc in the Single Loader slot

1

Press SINGLE LOADER ACCESS.

- The hood will open with the single loader slot located in the front of the unit.

2



Loading the disc into the Single Loader slot with the label side (printed surface) facing to the left.

3



Press SINGLE LOADER PLAY.

- The play mode is set to SINGLE.

Tips:

- The disc loaded in the Single Loader slot can also be selected using **DISC(–/+)**. It is located after disc No. 100 when **DISC(+)** is used or disc No. 1 when **DISC(–)** is used. On the display, it is shown as "P0".
- If a disc has been loaded in the Single Loader slot, pressing **SINGLE LOADER PLAY** allows to play it anytime, even during playback of a disc stored in the rack.
- To play the disc in the Single Loader slot using the remote control unit, press "**0**" and **DISC SET**.

The hood can be opened or closed during playback.

1

Press and hold OPEN/CLOSE until "OPEN" is displayed.

- **"HOLD"** is displayed.
- In this case, the rack does not rotate.
- When the playback of the current disc has completed, the unit enters stop mode. The next disc is played after the hood has been closed.

2

To close the hood, press OPEN/CLOSE again.

Note!!

*If the hood is opened during play, **UNLOAD**, **SINGLE LOADER ACCESS** and **DISC (-/+)** are defeated.*

VARIOUS OPERATIONS

- The remote control is the most convenient way to perform these operations.



- **The parenthesis ( ) show operations for the main unit.**



To program and play only the discs you want to hear (CUSTOM play)

This unit lets you program up to 100 of your favorite discs. For example, you can store all the discs of your favorite artist, or some other group of personal selections, and play only those discs.
You can even add other discs to the custom later on.

Operation example: **Storing discs 3 and 12 in the CUSTOM II file.**

1



During stop mode, press MODE so that the CUSTOM II indicator lights.



- If some disc number appears, press CLEAR.

2



Use the digit buttons to select disc.



- If you use **DISC (–/+)** to select a disc, it will be programmed automatically after approximately 2 seconds.

3



Press DISC SET.



4



Repeat steps 2 and 3 to store other discs.





Press MODE to select CUSTOM and press ►.

Playback starts from the lowest disc No.

Checking the numbers of the stored discs.

Press **TIME** repeatedly (3 times) during stop mode so that the display changes as shown below.
Press **DISC(–/+)**. Each time you press **DISC(–/+)**, a disc number stored in the CUSTOM file is displayed. When all the disc numbers have been displayed, the disc number changes to a blank.

Erasing all the discs from the each CUSTOM file.

Press **MODE** to choose CUSTOM, then press the **CLEAR** button on the front panel.

Note!!
You cannot change the discs stored in the CUSTOM file. Likewise, you cannot erase just one disc from the CUSTOM file.

- Pressing **DISC (–/+)** during CUSTOM playback lets you choose among other discs stored in the CUSTOM file.
- If you use the **digit** buttons and **DISC SET** on the remote control during CUSTOM playback to choose a disc not stored in the CUSTOM file, **"** no dISC"** will be displayed for approximately 3 seconds.
- The discs stored in the CUSTOM file will not be erased when you turn off the power.
- When a disc appointed to the CUSTOM file is not loaded in the rack, **"** no dISC"** is displayed for approximately 3 seconds, the disc is erased from memory, and CUSTOM searches for the next disc.
- Items stored in memory are saved for approximately 2 days, even if the power cord is unplugged. However, this period may be shortened somewhat, depending on the amount of memory used. **(Memory Back-Up Function).**
- While the hood is open, **DISC (-/+)** cannot be used for CUSTOM file entry.

- You can also use the remote control.



To start playback from a specific disc



Press DISC (–/+) during play or pause to choose a disc number. During pause, press ►/II after choosing the disc.

- Playback starts from the first track of the chosen disc.

- When using the remote control, press **DISC (–/+)** to choose a disc, then press ► to start playback.

To play a track you want to hear



Press I◄◄◄◄/►►►►I during play or pause to choose the track number you desire (or press I◄◄/►►I on the remote control).

During pause, press ►/II after choosing the track.

To repeat playback (REPEAT play)



Press the REPEAT button during playback. Each time you press the button, the repeat mode changes as follows.

One track repeat → ALL repeat (ALL/SINGLE/CUSTOM) → OFF

One track

ALL

SINGLE



CUSTOM



(One track repeat)

Repeats the current or a selected track in during other play operations than HI-LITE scan and PREVIOUS scan.

(ALL repeat)

Repeats in one of the following 3 ways according to the play mode .

ALL: Repeats all the tracks on all the discs (1 - 100).

SINGLE: Repeats all the tracks on the selected disc.

CUSTOM: All of the discs classified under one of the three CUSTOM banks are played repeatedly.

(OFF)

Cancels repeat play and returns the unit to normal play mode.

- To stop repeat playback, press ■.
- When none of the ALL, SINGLE or CUSTOM play mode is displayed (i.e. during PROGRAM play, BEST play, PREVIOUS scan or HI-LITE scan), the tracks which would be played with these functions are be played repeatedly.





To playback tracks/discs at random (RANDOM play)

RANDOM selects tracks at random from the disc(s) in the current play mode and plays each track once. Playback stops when all the tracks on the disc(s) have played back once.

Play mode selected	Play contents
ALL	Plays up to 100 tracks at random from among all the discs (1 - 100).
SINGLE	Plays all the tracks from a single disc at random.
CUSTOM	Plays up to 100 tracks at random from the discs into one of three groups in CUSTOM file.

Press RANDOM during either play or stop mode.



To stop random play, press ■.

Notes!!

- *Random play cannot be activated during the program mode. (If you press **RANDOM** during program play or best play, the program contents will be erased and the unit will start to play tracks at random from all the discs.*
- *In the ALL or CUSTOM (I, II or III) mode, if less than 100 discs are loaded, the same track may be played.*
- *If you press **REPEAT** during random play, the contents of the random mode are repeated. (RANDOM REPEAT)*
- *If you press **DISC (–/+)** during random play, random play is canceled.*
- *If you press **MODE** during random play, random play is switched to the ALL or SINGLE play.*

To program tracks/discs in a desired order (PROGRAM play)

- The remote control is the most convenient way to perform these operations.
- You can program up to 32 steps.
- **The parenthesis ( ) show operations for the main unit.**



Operation example: **Programming disc 2, track 7 as step 1, and disc 5, track 3 as step 2.**

1 PGM / PROGRAM (O)

Press PGM (PROGRAM) during stop mode.

2 2 / SET / DISC / DISC (−/+) → PROGRAM (O)

Use the digit buttons to select the disc, then press DISC SET.

(Use **DISC (−/+)** to select the disc number, then press **PROGRAM**.)



The PGM indicator starts to blink.

3 7 / SET / TRACK / PROGRAM (→ O)

Use the digit buttons to select the track, and press TRACK SET.

(Use ⏮◀◀/▶▶⏭ to select the track number, then press **PROGRAM**.)



4 5 / DISC / 3 / TRACK / DISC (−/+) → PROGRAM → PROGRAM (O)

Repeat steps 2 and 3 to program additional discs and tracks.

Once the track times have been added, the PGM indicator stops blinking and the following display appears (Total Time).



5 ▶ / (▶/II)

Press ▶.

The program play starts from the track that was programmed first.

- Items stored in memory are saved for approximately 2 days, even if the power cord is unplugged. However, this period may be shortened somewhat, depending on the amount of memory used. **(Memory Back-Up Function).**

The following operations can only be performed during normal play, HI-LITE scan or PREVIOUS scan

<Programming tracks during normal play>

(Direct program)

1. Press **PGM (PROGRAM)**.
   - Program mode is activated.
2. Press **PGM (PROGRAM)** during playback.
   - The current track is programmed.

<Programming during normal playback (remote control only)>

(Preprogramming)

You can program during normal playback.

(➡Operation example 1 2 3 4)

- The player changes to program play when the current track finishes playing back.
- To change to program mode directly, press ▶.

The following operations can only be performed during stop mode

<Programming an entire disc as one step>

(Disc all program)

If you skip step 3 of the operation example, disc 2 is programmed as step 1.

<Programming a pause (remote control only)>

(Pause program)

If you press **II** at step 4, you can program a pause. When you press **II**, "PA" appears in the display instead of the disc number.

- For example, when making a program for recording both sides of a cassette tape, press **II** to insert a pause after programming the tracks for one side. After turning the tape over, press **II** to resume recording.

> ***Notes!!***
> - *You cannot program a pause as the first step, or program two pauses in a row.*
> - *When you program a pause, it counts as 1 step and reduces the total number of tracks you can program.*

- **To erase a program...**
  Press ■ twice during playback (or once in stop mode). Press **MODE** or **RANDOM** in either play or stop mode. You can also erase the program by pressing **MODE**, **RANDOM**, **PREVIOUS**, or **SINGLE LOADER** in play or stop mode (or by pressing **BEST** in stop mode).
- **To cancel a program step**
  In stop mode, each time you press **CLEAR** on the front panel, the last step in the program is erased.
  - If a programmed disc is missing or inserted backwards during program play, **"** no dISC"** appears in the display, the step is automatically erased, and playback proceeds to the next step.
  - Program contents are stored in memory even when the power is turned off (STANDBY).

Notes!!

- *If step 5 is carried out before the accumulated time is displayed, the program play starts and the time is not displayed.*
- *When UNLOAD is pressed while a program has been entered, the disc for the 1st program step comes on the center position and the hood opens.*
- *The display is not shown if the total time of the program is 100 minutes or more.*

- You can also use the remote control for these operations.
- **These operations can not be performed on the CD inserted into the SINGLE LOADER SLOT.**





To store your favorite tracks (BEST play)

To use the one-touch memory, just press the BEST button while playing a track you like. You can store up to 20 tracks.

BEST

Press BEST while playing a track you like.

The BEST indicator flashes and the disc and track number are stored in memory.

<To listen to the memorized tracks>

BEST

Press BEST during stop mode.

The BEST indicator lights and playback starts from the most recently memorized track.

- If you press **CLEAR** during Best playback, the current track is erased and the next track starts to play.
- You cannot memorize a track twice by pressing **BEST** during Best playback.
- The memorized contents are stored, even when the power is turned off (STANDBY).
- If you press **BEST** to memorize a track when 20 tracks are already memorized, the oldest track is erased from memory and the new track is memorized.
- The disc loaded in the Single Loader slot cannot be memorized in the BEST tracks.
- Items stored in memory are saved for approximately 2 days, even if the power cord is unplugged. However, this period may be shortened somewhat, depending on the amount of memory used. **(Memory Back-Up Function).**

To find out which discs you've listened to recently (PREVIOUS scan)

- **This function scans the discs in reverse order, starting from the last disc you played.**
- **It can remember up to 20 discs. If the total number of discs exceeds 20, the oldest disc will be erased to make room for the new disc.**

Example: If you played discs 1, 2, 9, 12 and 13 in order.

PREVIOUS

Press the PREVIOUS button.

- Approximately 10 seconds from one minute into the first track of each disc is played back, starting from the last disc you played: 13, 12, 9, 2, 1.



Blink

▶

Press ▶ (or ▶/II) when you reach the disc you want to hear.

- Previous disc scan is canceled and normal play resumes.

- To cancel the scanning, press ■.
- Discs played during random, program, HI-LITE scan, Best and Single Loader playback are not included in the PREVIOUS scan.
- If the first track is less than 1 minute long, about 10 seconds from the beginning will be played. If the first track is less then 10 seconds long, the entire track will be played.
- Items stored in memory are saved for approximately 2 days, even if the power cord is unplugged. However, this period may be shortened somewhat, depending on the amount of memory used. **(Memory Back-Up Function).**

- You can use the remote control.



To scan quickly through tracks on a disc (HI-LITE scan)

This function plays a 10 second portion located 1 minute from the start of each track on all the discs in the current play mode.

<Disc scan>

HI-LITE

Press once

Press HI-LITE during either play or stop mode.

- The unit plays a 10 second portion located 1 minute into the first track of each CD, starting from the first CD.

The "DISC" and "SCAN" indicator blinks.

<Track scan>

HI-LITE

Press twice

Press HI-LITE twice during either play or stop mode.

- The unit plays a 10 second portion located 1 minute into each track of each CD, starting from the first CD.

The "SCAN" indicator blinks.

<Program scan>

HI-LITE

Press once

Press HI-LITE during program mode.

- The unit plays a 10 second portion located 1 minute into each track in the program.

The "SCAN" indicator blinks.

<Best selection memory scan>

HI-LITE

Press once

Press HI-LITE during best selection memory playback.

- The unit plays a 10 second portion located 1 minute into each track in the best selection memory.

The "SCAN" indicator blinks.

<To return to normal playback>

►



Press ► (or ►/II) when you reach the track you want to hear.
HI-LITE scan is canceled and normal play resumes.

- To cancel HI-LITE scan, press ■.

Notes!!

- *You can use I◄◄ /►►I to skip to another track during track scan.*
- *If the player is in ALL REPEAT mode, the HI-LITE scan will repeat.*
- *If the track is less than 1 minute long, about 10 seconds of the track will be played. If the track is less then 10 seconds long, the entire track will be played.*



ADLC (Automatic Digital Level Controller)

Press ADLC.

- Turn off ADLC, press ADLC so that the ADLC indicator goes off.

When the difference of recording level between discs is noticeable, the volume level should be adjusted for each discs, especially during program playback or random playback when tracks are selected between 2 discs or more. In such cases, pressing ADLC automatically sets the output level to the proper level. When ADLC is turned on, the ADLC indicator lights.

Note!!
With some selection, sound becomes unnatural. In such cases, turn off ADLC.



To use the TIME button



Press TIME during playback.
Each time you press **TIME**, the display changes as follows.

Disc number, Track number and Elapsed Time.
↓
Remaining time (TRACK)
↓
Remaining time (DISC)
↓
Total elapsed time (TOTAL)

Notes!!

- *Time remaining on the disc is not displayed during RANDOM, PROGRAM or BEST play.*
- *Time remaining on the track may not be displayed for tracks numbered greater than 24.*
- *During PROGRAM play*

Disc number, Track number and Elapsed Time.
↓
Remaining time (TRACK)
↓
Total program time and number of steps (TOTAL)

- *During BEST play*

Disc number, Track number and Elapsed Time.
↓
Remaining time (TRACK)
↓
Total number of steps memorized in BEST (TOTAL)

Caution in use of the optional PD-AP1 File-type CD Controller (except for U.K. model)

- When the PD-AP1 is connected to the PD-F905, disc replacement should be done by using the **DISC (+/–)** after opening the hood.
  (The **DISC (+/–)** will not function when the hood is open.)
  Note!!
  DISC (-/+) *of the remote control unit cannot be used.*
- The disc in the SINGLE LOADER slot can be played only when the PD-F905 is connected with the PLAYER 1 section of the PD-AP1.

Note!!
If the PD-F905 is connected with the PLAYER 2 or 3 section of the PD-AP1, the disc can be loaded in the slot but cannot be played.

- When the PD-AP1 is connected to the PD-F905, the BEST play, PREVIOUS scan and HI-LITE scan functions of the PD-F905 cannot be used.
- When the PD-AP1 is connected to the PD-F905, the time display on the PD-F905 will read "– –".

TROUBLESHOOTING

Incorrect operations are often mistaken for trouble and malfunctions. If you think that there is something wrong with this component, check the points below. Sometimes the trouble may lie in another component. Investigate the other components and electrical appliances being used.
If the trouble cannot be rectified even after exercising the checks listed below, ask your nearest PIONEER authorized service center or your dealer to carry out repair work.

Symptom	Cause	Remedy
No sound	• Output cables are connected incorrectly or loosely. • Incorrect operation of stereo amplifier. • Pin plugs and/or amplifier terminals are dirty. • Player is in pause mode. • The disc is loaded with the label side rightward.	• Connect properly. • Check the settings of amplifier switches and sound volume controls. • Clean away dirt. • Press ► or ❚❚. • Reload the disc with the label side leftward.
When playback is started, it stops immediately. Pauses or stops during playback.	• Disc is inserted in the wrong way. • Smudges, etc., on the disc.	• Insert the disc correctly with the label side leftward. • Clean the smudges from the disc and then play it again.
Remote control will not function.	• Dead batteries. • Obstruction between player and remote control unit.	• Replace batteries. • Relocate remote control unit or remove obstruction.

Abnormal functioning of this unit may be caused by static electricity, or other external interference. To restore normal operation, turn the power off and then on again, or unplug the AC power cord and then plug it in again.

SELF-DIAGNOSTICS FUNCTION

The unit incorporates the self-diagnostic function.
When an abnormality is detected during operation of the unit, an error message (service No.) appears on the unit's display automatically. Treat the error by following the instructions in **"Countermeasures"**.

Display on the unit



Service No.	Unit Status	Countermeasures
U1	The disc may not be loaded properly in the rack.	• Reload the discs properly. (Insert only one disc in a slot.) • Check if there is a foreign object attached onto the disc. • Check if there is a foreign object in the rack.
U2	There is an operation error in the mechanical section.	• Check if there is a foreign object in the rack. • Unplug the power cord then plug it in again.
U3	There is an error related to the hood.	• Check if the hood is caught by anything. • Unplug the power cord then plug it in again.
If the same display appears again, there may be an error in the mechanical section. When requesting servicing, please also let us know the service number displayed on the unit.		

SPECIFICATIONS

1. General

Type ..... Compact disc digital audio system
Power requirements
U.S. model ..... AC 120V, 60 Hz
U.K. model ..... AC 240V, 50/60 Hz
European model ..... AC 220-240V, 50/60 Hz
Power consumption
U.S. model 14W
U.K. model 14W
European model 14W
Operating temperature ..... +5°C - +35°C (+41°F - +95°F)
Weight (without package) ..... 6.5 kg (14 lb 5 oz.)
External dimensions ..... 420(W) X 402(D) X 190(H) mm 16-9/16(W) X 15-13/16(D) X 7-1/2(H) in.

2. Audio section

Frequency response ..... 2 Hz - 20 kHz
S/N ratio ..... 98 dB or more (EIAJ)
Dynamic range ..... 96 dB or more (EIAJ)
Channel separation ..... 96 dB or more (EIAJ)
Harmonic distortion ..... 0.003 % or less (EIAJ)
Level difference between channels ..... 1.0 dB or less (EIAJ)
Output voltage ..... 2 ± 0.3 Vrms (EIAJ)
Wow and flutter ..... less than ±0.001 % (W.PEAK) (below measurable level) (EIAJ)
Channels ..... 2-channel (stereo)

3. Output terminal

Audio line output
Control input jack (Except for U.K. model)
Control output jack (Except for European and U.K. models)
CD-DECK SYNCHRO jack
Optical digital output jack
I/O interface (Except for U.K. model)
Head phone jack with volume control (Except for U.S. model)

4. Accessories

- Remote control unit 1
- Size AA/R6P dry cell batteries 2
- Output cable 1
- Control cable (Except for European and U.K. models) 1
- CD liner notes file 1
- Index label sheet 1
- Operating instructions 1

NOTE:

Specifications and design subject to possible modification without notice, due to improvements.

Published by Pioneer Electronic Corporation.
Copyright © 1996 Pioneer Electronic Corporation.
All rights reserved.

Dear Customer:

Selecting fine audio equipment such as the unit you've just purchased is only the start of your musical enjoyment. Now it's time to consider how you can maximize the fun and excitement your equipment offers. This manufacturer and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion-and, most importantly, without affecting your sensitive hearing.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

To establish a safe level:

- Start your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.

Once you have established a comfortable sound level:

- Set the dial and leave it there.

Taking a minute to do this now will help to prevent hearing damage or loss in the future. After all, we want you listening for a lifetime.

We Want You Listening For A Lifetime

Used wisely, your new sound equipment will provide a lifetime of fun and enjoyment. Since hearing damage from loud noise is often undetectable until it is too late, this manufacturer and the Electronic Industries Association's Consumer Electronics Group recommend you avoid prolonged exposure to excessive noise. This list of sound levels is included for your protection.

Decibel Level	Example
30	Quiet library, soft whispers
40	Living room, refrigerator, bedroom away from traffic
50	Light traffic, normal conversation, quiet office
60	Air conditioner at 20 feet, sewing machine
70	Vacuum cleaner, hair dryer, noisy restaurant
80	Average city traffic, garbage disposals, alarm clock at two feet.

THE FOLLOWING NOISES CAN BE DANGEROUS UNDER CONSTANT EXPOSURE

90	Subway, motorcycle, truck traffic, lawn mower
100	Garbage truck, chain saw, pneumatic drill
120	Rock band concert in front of speakers, thunderclap
140	Gunshot blast, jet plane
180	Rocket launching pad

Information courtesy of the Deafness Research Foundation.

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS [USA] INC. P.O. BOX 1540, Long Beach, California 90801-1540
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway, Markham, Ontario L3R 0P2, Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium TEL: 03/570.05.11
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia, TEL: [03] 9586-6300
PIONEER ELECTRONICS DE MEXICO S.A. DE C.V. San Lorenzo Num 1009 3er Piso Desp. 302 Col. Del Valle, Mexico D.F. C.P.03100 TEL: 5-688-52-90

<96E01ZF3D02>

Printed in Japan <PRB1237-B>